

imminet.com





Safety doesn't have to be uncomfortable.

Encourage seat belt use by making them more comfortable to wear with IMMI's Komfort Latch®. A breakthrough in seat belt comfort and convenience, IMMI's Komfort Latch simply and safely relieves seat belt tension.

In normal driving conditions with the Komfort Latch engaged, the seat belt is allowed to extend/retract 5 to 7 inches for greater freedom of movement. Quick and easy to use, the Komfort Latch makes it easier for the driver to lean forward, make full steering wheel turns, and to check their side mirrors while remaining safely and comfortably buckled up.

Should the vehicle experience a sudden deceleration while the Komfort Latch is in use, the seat belt will still lock as needed.







KomfortLatch#®

How it Works:

Gen 1:

Engaging the Komfort Latch

- 1. Latch seat belt (visit www.clicktugsnug.com)
- 2. Release Komfort Latch lever by pulling it down.
- 3. Properly adjust the seat belt height adjuster.
- 4. Pull the shoulder belt a small distance away from your chest. Pull out only enough webbing so you can insert two fingers (approximately 1" or 2.5 cm) between the shoulder belt and your chest.
- 5. With your other hand lift up the Komfort Latch lever until it secures the web.
 - * If the vehicle experiences a sudden deceleration while the Komfort Latch is in use, the device will allow the retractor to fully lock the belt.

Disengaging the Komfort Latch

Lean forward in the seat, pulling on the shoulder belt, or reach up and pull down the Komfort Latch lever. The Komfort Latch will disengage and allow the seat belt to retract.

Gen 2:

Engaging the Komfort Latch

- 1. Latch seat belt (visit www.clicktugsnug.com)
- Push the yellow button to engage the Komfort Latch
- 3. Lean forward (about 4") until you hear a click
- 4. Return to normal driving position, and the latch maintains the preset amount of slack (approximately 1 inch).*
 - * If the vehicle experiences a sudden deceleration while the Komfort Latch is in use, the device will allow the retractor to fully lock the belt.

Disengaging the Komfort Latch

- 1. Unlatch the seat belt
- 2. Push the yellow button to disengage the Komfort Latch OR tug on the upper torso portion of the seat belt.



On the bright side...



Did You Know?

A mandatory seat belt usage program can save lives - and money.

- The fewer times your drivers are pulled over for not wearing seat belts, the better your CSA scores.
- It generally costs less than \$10 per seat to spec high visibility web at the time of build versus retrofitting at an approximate cost of \$200 a seat!
- Your drivers have a better chance of walking away from an accident if they are wearing their seat belts.





To get your Click Tug Snug training video, visit **clicktugsnug.com.**